4243 Gatecrest, Suite 103,
San Antonio TX 78217
(210) 368-9248

Tech Data Sheet

Throttle Body Air Intake Cleaner

THROTTLE BODY AIR INTAKE CLEANER

A powerful blend of detergents and solvents for rapid break down and removal of sludge, varnish, and gum deposits from fuel delivery systems on all gasoline fueled engines. "Sensor friendly"

Benefits

- Removes carbon, gum and varnish
- Cleans emissions system sensors
- Helps eliminate rough idling and stalling
- Cleans and protects the throttle body and Idle Air Control Valve (IAC)
- Safe for oxygen sensors and catalytic converters.
- Will not harm Teflon coating
- Useful on all types of fuel injected gasoline engines found in cars, pickups, trucks, SUV's, vans, heavy-duty, and small horsepower engines

Applications

Recommend in use of all gas naturally aspirated, turbo and supercharged engines.

Directions

Caution: Do not spray through air filter or across mass air flow sensor. Start engine and bring to normal operating temperature. Shut engine off, disconnect air induction tube or air filter assembly. Place shop rag under throttle body unit to collect any run off. Move butterfly valve back and fourth and spray contents of can directly on front of valve, back of valve and around the wall of throttle body unit. For extra dirty units, soak a brush or rag and wipe area where dirty. Remove shop rag and start engine. Spray contents directly into the throat using short spray bursts in a circular pattern until unit is clean. NOTE: Engine may not run with mass air flow sensor disconnected. In this case you must complete the service with the engine off. When finished, reconnect induction tubes or air cleaner assembly. IMPORTANT: Do not spray on painted or plastic surfaces.

Dirty Throttle Body



Clean Throttle Body



Part#	Pack	Treats
RT2804	4oz	N/A
DR2804	55 Gallons	N/A
T3302804	330 Gallons	N/A

4243 Gatecrest Suite 103
San Antonio, Texas 78217
Phone (210) 368-9248
www.maxxmarka.com

Copyright © MAXXMARKA, INC. All rights reserved.

PRODUCTS MADE IN THE U.S.A